

**TURCK**

Your Global Automation Partner

# Turck Safety Configurator Installation and Licensing

Technical Support Document

# Contents

<b>1</b>	<b>About these instructions .....</b>	<b>3</b>
1.1	Explanation of symbols .....	3
1.2	Feedback about these instructions .....	3
<b>2</b>	<b>Notes on the product .....</b>	<b>4</b>
2.1	Product identification .....	4
2.2	Prerequisites .....	4
2.3	Turck service .....	4
<b>3</b>	<b>Product description .....</b>	<b>5</b>
3.1	License model Turck Safety Configurator .....	5
<b>4</b>	<b>Installing and licensing of Turck Safety Configurator .....</b>	<b>6</b>
4.1	Downloading the software .....	6
4.2	Installing a single-user license (Option standard installation) .....	7
4.3	Installing and activating a floating license (Option virtual machine) .....	10
4.3.1	Installing the floating license on multiple workstations.....	13
<b>5</b>	<b>Managing licenses .....</b>	<b>15</b>
5.1	Creating and expanding a license pool from floating licenses.....	16
5.2	Using a floating license as a borrowed license (offline operation of the software) .....	18
5.2.1	Activating a borrowed license (with internet access) .....	18
5.2.2	Activating a borrowed license (no internet access).....	20
5.2.3	Deleting a borrowed license (with internet access) .....	21
5.2.4	Deleting a borrowed license (no internet access) .....	22
5.3	Deleting a license.....	24
<b>6</b>	<b>Turck branches — contact data .....</b>	<b>25</b>

# 1 About these instructions

This document describes the license model and the installation of the Turck Safety Configurator depending on the selected license.

## 1.1 Explanation of symbols

The following symbols are used in these instructions:



**DANGER**

DANGER indicates a hazardous situation with a high level of risk, which, if not avoided, will result in death or serious injury.



**WARNING**

WARNING indicates a hazardous situation with a medium level of risk, which, if not avoided, will result in death or serious injury.



**CAUTION**

CAUTION indicates a hazardous situation with a medium level of risk, which, if not avoided, will result in moderate or minor injury.



**NOTICE**

CAUTION indicates a situation which, if not avoided, may cause damage to property.



**NOTE**

NOTE indicates tips, recommendations and important information about special action steps and issues. The notes simplify your work and help you to avoid additional work.



**MANDATORY ACTION**

This symbol denotes actions that the user must carry out.



**RESULT OF ACTION**

This symbol denotes the relevant results of an action.

---

## 1.2 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to [techdoc@turck.com](mailto:techdoc@turck.com).

## 2 Notes on the product

### 2.1 Product identification

This document is valid for the software tool Turck Safety Configurator.

### 2.2 Prerequisites

Hardware required:

- PC with Microsoft Windows

Software required:

- Windows 7 or higher
- Turck Safety Configurator
- Coupon code
- Browser

The Turck Safety Configurator (TSC) is available for download as ZIP archive at [https://www.turck.de/en/product/SW\\_Turck\\_Safety\\_Configurator](https://www.turck.de/en/product/SW_Turck_Safety_Configurator).

### 2.3 Turck service

Turck supports you in your projects – from the initial analysis right through to the commissioning of your application. The Turck product database at [www.turck.com](http://www.turck.com) offers you several software tools for programming, configuring or commissioning, as well as data sheets and CAD files in many export formats.

The contact data for Turck branches is provided at [▶ 25].

## 3 Product description

The software tool Turck Safety Configurator serves for configuring the Turck Safety I/O modules.

### 3.1 License model Turck Safety Configurator

The Turck Safety Configurator can be installed as a single user license or as a floating license.

#### Single user license

The Turck Safety Configurator is installed and registered on a PC with the single user license and can also be used offline without Internet access on the PC.

#### Floating license

With the floating license, the Turck Safety Configurator can be used on any number of workstations (local PC or virtual machine). The number of floating licenses purchased determines how many users can work with the software at the same time. The license server registers the number of floating licenses currently assigned and manages the allocation of licenses. If all floating licenses are used, an additional user must wait until a license is available again to be able to use it. Using the software with a floating license therefore requires a permanent Internet connection to the license server.

In cases of limited Internet connection, a borrowed license for operation in offline mode can be generated for a maximum period of 30 days (see [▶ 18]).

#### License overview

License	Validity	No. of users (simultaneous use)	Connection to license server (Internet access) necessary	Transfer
Single-user license [▶ 7]	Unlimited	1	No	No
Floating license [▶ 10]	Unlimited	n, depends on the number of licenses purchased	Yes	Yes
■ Borrowed license [▶ 18]	1...30 days	1	No	No

## 4 Installing and licensing of Turck Safety Configurator

### 4.1 Downloading the software

The Turck Safety Configurator (TSC) is available for download as ZIP archive at [https://www.turck.de/en/product/SW\\_Turck\\_Safety\\_Configurator](https://www.turck.de/en/product/SW_Turck_Safety_Configurator).



#### NOTE

A coupon code is required to download the software. The code can be requested from Turck customer service. Further information can be found on the product page of the software.

- ▶ Enter coupon code.




Fig. 1: Turck Safety Configurator: entering the coupon code

- ▶ Download the software. Turck recommends to always use the latest version of the software.




Fig. 2: Turck Safety Configurator: download

- ▶ Unpack the zip archive and install the Turck Safety Configurator.

## 4.2 Installing a single-user license (Option standard installation)

Prerequisites:

- The software was downloaded.
- The zip archive was unpacked.
- ▶ Execute the installation file "install.exe", select the installation language and click **Install**.

To install the single user license, the installation of the floating license must be deactivated.

- ▶ In the **Custom setup** window, deactivate the **Option virtual machine** (floating license) as follows:




Fig. 3: Deactivating the option virtual machine

- ▶ Select the installation of the single-user license via the setting **Option standard installation** → **Will be installed on the local hard drive:**




Fig. 4: Selecting the standard installation

- ▶ Click **Next** to start the installation of the single-user license. The installation wizard guides through the installation.

### Licensing a single-user license

The license must be activated when the Turck Safety Configurator is started for the first time after installation.

- ▶ Start the Turck Safety Configurator.
- ▶ Confirm the following dialog with **Yes**.




Fig. 5: Dialog box: no valid license found

- ▶ Add the coupon code in the **Add new license** window.

**Add license**

← Add new license

Please enter your license data

Please choose whether you want to redeem a coupon code online or already have a license key:

Coupon code

Note: This requires Internet access. If you do not have Internet access on this computer you can visit our activation website on another computer to redeem your coupon code and receive a license key. You may need the following hardware ID.

Web registration:

Your hardware ID:

License key

[Lost your license data?](#)

Next > Cancel Help

Fig. 6: Entering the coupon code

#### Transferring a single user license to other hardware

- ▶ Delete the license in the license manager [▶ 24].
- ▶ Uninstall the Turck Safety Configurator.



#### NOTE

If it is not possible to uninstall the software and delete the license due to a hardware defect, please contact the Turck customer service:  
TM-BWSoftwareSupport@turck.com.

## 4.3 Installing and activating a floating license (Option virtual machine)

### Installing a floating license

Prerequisites:

- The software was downloaded.
- The zip archive was unpacked.
- ▶ Execute the installation file "install.exe", select the installation language and click **Install**.

To install the floating license, the installation of the single user license must be deactivated.

- ▶ In the **Custom setup** window, deactivate the **Option standard installation** (single user license) as follows:




Fig. 7: Deactivating the standard installation

- ▶ Select the installation of the floating license via the setting **Option virtual installation** → **Will be installed on the local hard drive**:




Fig. 8: Installing the floating license (Option virtual machine)

- ▶ Click **Next** to start the installation of the floating license. The installation wizard guides through the installation.

### Licensing a floating license

The license must be activated when the Turck Safety Configurator is started for the first time after installation.

- ▶ Start the Turck Safety Configurator.
- ▶ Confirm the following dialog with **Yes**.




Fig. 9: Dialog box: no valid license found

- ▶ Add the coupon code in the **Add new license** window.

**Add license**

← Add new license

### Please enter your license data

Please choose whether you want to redeem a coupon code online or already have a license key:

Coupon code

Note: This requires Internet access. If you do not have Internet access on this computer you can visit our activation website on another computer to redeem your coupon code and receive a license key. You may need the following hardware ID.

Web registration:

Your hardware ID:

License key

[Lost your license data?](#)

Next > Cancel Help

Fig. 10: Entering the coupon code

#### 4.3.1 Installing the floating license on multiple workstations

A floating license can be installed and used on any number of workstations (local PC or virtual machine). In addition, a license pool consisting of several licenses can be set up [▶ 16].

After installing and updating the floating license on the first workstation (local PC or virtual machine), the license can be installed on an unlimited number of additional workstations. The first installation serves as the source for all other installations.

Licenses are managed via the license manager. The license manager is installed with the Turck Safety Configurator and is started via **Start** → **Turck Software** → **license manager**.

Prerequisites:

- The Turck Safety Configurator is installed and activated with the "option virtual machine" (floating license) on the first workstation.

Procedure:

- ▶ Install the Turck Safety Configurator on any number of additional workstations (local PC or virtual machine) with the "Option virtual machine" (floating license).
- ▶ Transfer the license data from the first activation to all other workstations. Two options are available for this:

Importing license data from the source installation (recommended)

- ▶ Open the license manager of the source installation and click **Export** to generate and store a license file (\*.licstor) with the license data of the source installation.




Fig. 11: License manager: export of a license

- ▶ Copy the license data to all workstations, on which the license is to be used.

- ▶ Open the license manager on the respective workstations and import the license data (\*.licstor).




Fig. 12: License manager: import of a license

#### Transferring license data manually

- ▶ Activate the floating license manually on all workstations using the license data from the initial installation (s. "Licensing a floating license" [▶ 11]). The license data must exactly match the license data of the initial installation.

## 5 Managing licenses

The license manager is used to manage the Turck Safety Configurator licenses and is installed during the installation of the Turck Safety Configurator.

The license manager can be used to add purchased licenses, import licenses from other workstations, export licenses for use on other workstations or delete them completely if they are no longer required.




Fig. 13: License manager with single-user license

When using floating licenses, the license manager offers additional functions such as creating a license pool and generating borrowed licenses.




Fig. 14: License manager with floating license

## 5.1 Creating and expanding a license pool from floating licenses

Floating licenses can be combined into a license pool in the license manager. To create a license pool, the Turck Safety Configurator is first installed on any number of workstations. The same coupon code is used to activate the license on all workstations.

The initial installation of the software is considered the source installation, the license used is considered the source license. The license pool can be expanded as required by purchasing additional floating licenses.



### NOTE

The license pool can only be expanded with licenses that have not yet been used.

### Expanding the license pool

Prerequisites:

A floating license has been purchased and the corresponding license (coupon code) is available.

- ▶ Start the license manager via **Start → Turck Software → license manager**.
  - ⇒ The currently valid floating licenses are displayed.
- ▶ Select the floating license whose license pool is to be increased.
- ▶ Click **License pool**, enter the coupon code of the new floating license under **Increment floating license pool** and click **Next**.




Fig. 15: Adding a new floating license

- ⇒ The number of floating licenses has been increased. The free licenses of the license pool can now be used on all workstations on which the source license is located.




Fig. 16: License pool

## 5.2 Using a floating license as a borrowed license (offline operation of the software)

If the software is to be used on a workstation without or with a limited internet connection, a floating license can be used to generate a borrowed license for operation in offline mode. The borrowed license is valid for a maximum of 30 days and occupies a license from the floating license pool for this period.



### NOTE

Time-limited licenses that are only valid for a fixed number of days, e.g. for test or training purposes, cannot be used to generate a borrowed license.

### 5.2.1 Activating a borrowed license (with internet access)

- ▶ Start the license manager via **Start** → **Turck Software** → **license manager**.
- ⇒ The currently valid floating licenses are displayed.
- ▶ Select the floating license from which a borrowed license is to be created.




Fig. 17: Valid floating licenses

- ▶ Click **Borrow license** and enter a license duration (max. 30 days).




Fig. 18: Creating a borrowed license

## Options

- **No local internet access, use internet access from another computer, s. "Activating a borrowed license without internet access" [▶ 20]**
- **Automatically renew the license every time the software starts (and an internet connection is available)**  
If this option is selected, the license is automatically returned for the specified duration when the licensing program is started and then borrowed again.
- ▶ Click **Next** and create a borrowed license.

### 5.2.2 Activating a borrowed license (no internet access)

A borrowed license can also be generated for use on a workstation that does not have internet access.

- ▶ Start the license manager via **Start → Turck Software → license manager**.
- ⇒ The currently valid floating licenses are displayed.




Fig. 19: Valid floating licenses

- ▶ Click **Borrow license** and enter a license duration (max. 30 days).




Fig. 20: Creating a borrowed license

- ▶ Click **Next**.
- ▶ Enter the generated activation key via another device (PC with internet access, smartphone or similar) on the Turck homepage under <https://www.turck.de/TSC-license-vm> and activate the license.




Fig. 21: Activation key for borrowed license without internet access

### 5.2.3 Deleting a borrowed license (with internet access)

- ▶ Select the borrowed license to be deleted, click **Delete license** and confirm the deletion with **Yes**.




Fig. 22: Deleting a license

- ▶ Click **Next** in the **Delete license** window and confirm deletion of the borrowed license with **Next**.




Fig. 23: Confirming the license deletion

- ⇒ The borrowed license is deleted

#### 5.2.4 Deleting a borrowed license (no internet access)

A borrowed license can also be generated for use on a workstation that does not have internet access.

- ▶ Start the license manager via **Start** → **Turck Software** → **license manager**.
- ⇒ The currently valid floating licenses are displayed.
- ▶ Select the borrowed license to be deleted, click **Delete license** and activate the function **No local internet access, use internet access from another computer**.




Fig. 24: Deleting a borrowed license, no internet access

- ▶ Click **Next** and generate a key for deactivating the borrowed license.




Fig. 25: Key for deleting a borrowed license (no internet access)

- ▶ Enter the generated key via another device (PC with internet access, smart phone or similar) on the Turck homepage under <https://www.turck.de/TSC-license-vm> and deactivate the license.




Fig. 26: Deactivating a license with key

- ⇒ The borrowed license is deleted from the license database.

### 5.3 Deleting a license

- ▶ Select the license to be deleted and click **Delete license**.




Fig. 27: Deleting a license

- ▶ Confirm the deletion of the license.

## 6 Turck branches — contact data

<b>Germany</b>	Hans Turck GmbH & Co. KG Witzlebenstraße 7, 45472 Mülheim an der Ruhr <a href="http://www.turck.de">www.turck.de</a>
<b>Australia</b>	Turck Australia Pty Ltd Building 4, 19-25 Duerdin Street, Notting Hill, 3168 Victoria <a href="http://www.turck.com.au">www.turck.com.au</a>
<b>Austria</b>	Turck GmbH Graumanngasse 7/A5-1, A-1150 Vienna <a href="http://www.turck.at">www.turck.at</a>
<b>Belgium</b>	TURCK MULTIPROX Lion d'Orweg 12, B-9300 Aalst <a href="http://www.multiprox.be">www.multiprox.be</a>
<b>Brazil</b>	Turck do Brasil Automação Ltda. Rua Anjo Custódio Nr. 42, Jardim Anália Franco, CEP 03358-040 São Paulo <a href="http://www.turck.com.br">www.turck.com.br</a>
<b>Canada</b>	Turck Canada Inc. 140 Duffield Drive, CDN-Markham, Ontario L6G 1B5 <a href="http://www.turck.ca">www.turck.ca</a>
<b>China</b>	Turck (Tianjin) Sensor Co. Ltd. 18,4th Xinghuazhi Road, Xiqing Economic Development Area, 300381 Tianjin <a href="http://www.turck.com.cn">www.turck.com.cn</a>
<b>Czech Republic</b>	TURCK s.r.o. Na Brne 2065, CZ-500 06 Hradec Králové <a href="http://www.turck.cz">www.turck.cz</a>
<b>France</b>	TURCK BANNER S.A.S. 11 rue de Courtalin Bat C, Magny Le Hongre, F-77703 MARNE LA VALLEE Cedex 4 <a href="http://www.turckbanner.fr">www.turckbanner.fr</a>
<b>Hungary</b>	TURCK Hungary kft. Árpád fejedelem útja 26-28., Óbuda Gate, 2. em., H-1023 Budapest <a href="http://www.turck.hu">www.turck.hu</a>
<b>India</b>	TURCK India Automation Pvt. Ltd. 401-403 Aurum Avenue, Survey. No 109 /4, Near Cummins Complex, Baner-Balewadi Link Rd., 411045 Pune - Maharashtra <a href="http://www.turck.co.in">www.turck.co.in</a>
<b>Italy</b>	TURCK BANNER S.R.L. Via San Domenico 5, IT-20008 Bareggio (MI) <a href="http://www.turckbanner.it">www.turckbanner.it</a>
<b>Japan</b>	TURCK Japan Corporation ISM Akihabara 1F, 1-24-2, Taito, Taito-ku, 110-0016 Tokyo <a href="http://www.turck.jp">www.turck.jp</a>

<b>Korea</b>	Turck Korea Co, Ltd. A605, 43, Iljik-ro, Gwangmyeong-si 14353 Gyeonggi-do <a href="http://www.turck.kr">www.turck.kr</a>
<b>Malaysia</b>	Turck Banner Malaysia Sdn Bhd Unit A-23A-08, Tower A, Pinnacle Petaling Jaya, Jalan Utara C, 46200 Petaling Jaya Selangor <a href="http://www.turckbanner.my">www.turckbanner.my</a>
<b>Mexico</b>	Turck Comercial, S. de RL de CV Blvd. Campestre No. 100, Parque Industrial SERVER, C.P. 25350 Arteaga, Coahuila <a href="http://www.turck.com.mx">www.turck.com.mx</a>
<b>Netherlands</b>	Turck B. V. Ruiterlaan 7, NL-8019 BN Zwolle <a href="http://www.turck.nl">www.turck.nl</a>
<b>Poland</b>	TURCK sp.z.o.o. Wroclawska 115, PL-45-836 Opole <a href="http://www.turck.pl">www.turck.pl</a>
<b>Romania</b>	Turck Automation Romania SRL Str. Siriului nr. 6-8, Sector 1, RO-014354 Bucuresti <a href="http://www.turck.ro">www.turck.ro</a>
<b>Sweden</b>	Turck AB Fabriksstråket 9, 433 76 Jonsered <a href="http://www.turck.se">www.turck.se</a>
<b>Singapore</b>	TURCK BANNER Singapore Pte. Ltd. 25 International Business Park, #04-75/77 (West Wing) German Centre, 609916 Singapore <a href="http://www.turckbanner.sg">www.turckbanner.sg</a>
<b>South Africa</b>	Turck Banner (Pty) Ltd Boeing Road East, Bedfordview, ZA-2007 Johannesburg <a href="http://www.turckbanner.co.za">www.turckbanner.co.za</a>
<b>Turkey</b>	Turck Otomasyon Ticaret Limited Sirketi Inönü mah. Kayisdagi c., Yesil Konak Evleri No: 178, A Blok D:4, 34755 Kadiköy/ Istanbul <a href="http://www.turck.com.tr">www.turck.com.tr</a>
<b>United Kingdom</b>	TURCK BANNER LIMITED Blenheim House, Hurrricane Way, GB-SS11 8YT Wickford, Essex <a href="http://www.turckbanner.co.uk">www.turckbanner.co.uk</a>
<b>USA</b>	Turck Inc. 3000 Campus Drive, USA-MN 55441 Minneapolis <a href="http://www.turck.us">www.turck.us</a>

# TURCK

Your Global Automation Partner

Over 30 subsidiaries and  
60 representations worldwide!

100048624 | 2023/11



[www.turck.com](http://www.turck.com)